

BULK WATER STATION

Located at: 700 9 Avenue North

If you experience difficulties or need to report a problem, please call Operational Services at 403.337.3446

DO NOT USE PUMPS TO PULL WATER FROM THE BULK WATER STATION

Our bulk water station requires a 3" male cam-lock and fill hose capable of handling 80 psi of pressure with sufficient length to reach from your vehicle to the cam-lock adaptor.

FILLING INSTRUCTIONS:

- 1. Shut off your vehicles engine and pumps before filling the tank.
- 2. Using clean hands/gloves, connect 3" male cam lock fitting on fill hose to bulk water station.
- Connect the other end of the fill hose to transport vehicle. *DO NOT HOLD FILL HOSE WHEN FILLING FROM BULK WATER STATION – INJURY MAY OCCUR*.
- 4. Ensure all fill valves are open on transport vehicle.
- 5. Enter your pin code into keypad on bulk water station and press **ENTER**.
- 6. Enter required load in litres, then press **ENTER** button to confirm.
- 7. To stop the filling process at any time, push and hold the red stop button.
- 8. Ensure water flow has completely stopped prior to hose disconnection.
- 9. Disconnect all hoses and fittings from bulk water station.
- 10. Close door to keypad when finished.

*Please note: The Town of Carstairs is not responsible for the quality of water once it leaves the bulk water station.